

Published: 11-May-2011

Interior Trim and Ornamentation -


Torque Specifications

Description	Nm	lb-ft
A-pillar trim panel Torx screw	3	2
A-pillar airbag deflector bracket bolts	9	7
B-pillar trim panel upper Torx bolt	25	18
C-pillar upper trim panel Torx screw	3	2
Engine cover 2.2 Diesel	10	7
Liftgate trim panel	1	1
Loadspace securing ring	25	18
Passenger assist handles	2	1
Sunvisors	2	1


Interior Trim and Ornamentation - A-Pillar Trim Panel

Removal and Installation

Removal



1.



2. NOTE: Do not disassemble further if the component is removed for access only.

Installation

1.  CAUTION: The airbag tether is mounted under this component. Do not trap during installation.
Install the A-pillar trim panel and tighten the new Torx screw to 3 Nm (2.2 lb.ft).

Interior Trim and Ornamentation - B-Pillar Upper Trim Panel


Removal and Installation

Removal

NOTE: Removal steps in this procedure may contain installation details.


1. Remove the B-pillar lower trim panel.

Refer to: [B-Pillar Lower Trim Panel](#) (501-05 Interior Trim and Ornamentation, Removal and Installation).




2.  **WARNING:** Make sure that a new bolt is installed.

Torque: 40 Nm




E75710

3. *Torque:* 25 Nm



E75711



E75712

4. NOTE: Do not disassemble further if the component is removed for access only.

5.



E75713

Installation


1. To install, reverse the removal procedure.

Interior Trim and Ornamentation - B-Pillar Lower Trim Panel

Removal and Installation


Removal

1.



E75707

2. NOTE: Do not disassemble any further if the component is removed for access only.



E75708

Installation


1. To install, reverse the removal procedure.

Interior Trim and Ornamentation - C-Pillar Trim Panel

Removal and Installation

Removal


NOTE: Removal steps in this procedure may contain installation details.



1.  **WARNING:** Make sure that a new bolt is installed.

Release the safety belt lower anchor.

Torque: 40 Nm



2. Release the rear door seal.

3. Release the rear quarter trim panel.




E77461

4.  **WARNING:** Make sure that a new bolt is installed.


Remove the C-pillar trim panel.

Torque: 3 Nm



E77462

5. NOTE: Do not disassemble further if the component is removed for access only.



E77463

Installation


1. To install, reverse the removal procedure.

Interior Trim and Ornamentation - D-Pillar Trim Panel

Removal and Installation


Removal

1. Remove the spare wheel cover.




E76943

2. Remove the loadspace scuff plate.




E76944


3. Release the liftgate seal.




E76945




4. Remove the loadspace stowage tray.



5. Remove the loadspace securing ring.



6. Release the rear quarter trim panel.



7. Remove the D-pillar trim panel.



E76950

8. **NOTE:** Do not disassemble further if the component is removed for access only.

Remove the speaker.

Installation

1. Install the speaker
2. Install the D-pillar trim panel.
3. Secure the rear quarter trim panel.
4. Install the loadspace securing ring and tighten the Torx screw.


Torque: 25 Nm

5. Install the loadspace stowage tray.
6. Attach the liftgate seal.
7. Install the loadspace scuff plate.
8. Install the spare wheel cover.

Interior Trim and Ornamentation - Front Door Trim Panel


Removal and Installation

Removal





E73384


1. Remove the grab handle cover.



2. Remove the front door trim panel.




E73385



E43315


- 3. NOTE: Do not disassemble further if the component is removed for access only.

Remove the puddle lamp.



E73386


- 4. Remove the front door latch remote control handle.



E73387

- 5. Remove the window control switch.

6. Remove the 11 clips.



E73388

Installation

1. Install the window control switch.
2. Install the front door latch remote control handle.
3. Install the puddle lamp.
4. Install the clips.
5. Install the front door trim panel.
6. Install the grab handle cover.

Interior Trim and Ornamentation - Rear Door Trim Panel


Removal and Installation

Removal

1. Disconnect the battery ground cable.


Refer to: [Specifications](#) (414-00 Battery and Charging System - General Information, Specifications).

- 2.




E73417

3. Remove the rear door trim panel.




E73418




4. NOTE: Do not disassemble further if the component is removed for access only.

Remove the rear door latch remote control handle.



- 5.



- 6.

Installation

1. Install the window control switch.
2. Install the rear door latch remote control handle.
3. Install the clips.
4. Install the rear door trim panel.

5. Install the grab handle cover.


6. Connect the battery ground cable.

Refer to: [Specifications](#) (414-00 Battery and Charging System - General Information, Specifications).

Interior Trim and Ornamentation - Liftgate Trim Panel


Removal and Installation

Removal



1.

2. NOTE: Do not disassemble further if the component is removed for access only.



Installation

1. To install, reverse the removal procedure.

Interior Trim and Ornamentation - Headliner Vehicles Without: Tilting Roof Opening Panel

Removal and Installation

Removal



CAUTION: Make sure that the wiring harnesses are correctly located.

NOTE: If a headliner is to be replaced, it is imperative that the washer hose and wiring harness are installed to their original positions. Failure to follow these instructions may impede the side air curtain module performance.

NOTE: Note the position of the wiring harnesses to aid installation.

1. Remove both A-pillar trim panels.

Refer to: [A-Pillar Trim Panel](#) (501-05 Interior Trim and Ornamentation, Removal and Installation).

2. Remove both B-pillar upper trim panels.

Refer to: [B-Pillar Upper Trim Panel](#) (501-05 Interior Trim and Ornamentation, Removal and Installation).


3. Remove both C-pillar trim panels.

Refer to: [C-Pillar Trim Panel](#) (501-05 Interior Trim and Ornamentation, Removal and Installation).

4. Remove both D-pillar upper trim panels.


Refer to: [D-Pillar Trim Panel](#) (501-05 Interior Trim and Ornamentation, Removal and Installation).

5. Remove the loadspace securing ring.



E77860

6. Remove the rear quarter trim panel.




7. Remove the glove compartment.


Refer to: [Glove Compartment](#) (501-12 Instrument Panel and Console, Removal and Installation).

8. Passenger side: Remove the cowl side trim panel.


Refer to: [Cowl Side Trim Panel](#) (501-05 Interior Trim and Ornamentation, Removal and Installation).

9. Passenger side: Remove the speaker grille.






10.




E77861



11.

E77862



12.


13. Remove the interior rear view mirror.

Refer to: [Interior Rear View Mirror](#) (501-09 Rear View Mirrors, Removal and Installation).

14. Remove the overhead console.


Refer to: [Overhead Console](#) (501-12 Instrument Panel and Console, Removal and Installation).

15. Remove the rear interior lamp.




E77864

16. Remove both sun visors.



E77865

17. Remove the 4 passenger assist handles.




E49689

18. Position the front seats fully forward.


19. Position the rear seats fully forward.

20. Release the rear of the headliner.





E77621

21. Release the front door seals.




22. Disconnect the washer jet hose.





23. **NOTE:** This step requires the aid of another technician.
Remove the headliner.




24. **NOTE:** Do not disassemble further if the component is removed for access only.
Remove the tire pressure monitoring system receiver.

25. **NOTE:** Make sure that this component is installed to the noted removal position.
Remove the washer jet hose.



26. **NOTE:** Note the position of the wiring harnesses to aid installation.
Remove the headliner wiring harness.

Installation



1.  **CAUTION:** Make sure that the wiring harnesses are correctly located.
 - Align the yellow tape on the wiring harness to the corner of the headliner.

2. Install the washer jet hose.
3. Install the tire pressure monitoring system receiver.
4. **NOTE:** This step requires the aid of another technician.
Install the headliner.
5. Connect the washer jet hose.
6. Attach the front door seals.
7. Attach the rear of the headliner.
8. Reposition the rear seats.
9. Reposition the front seats.
10. Install the passenger assist handles.
11. Install the sun visors.
12. Install the rear interior lamp.
13. Install the overhead console.

Refer to: [Overhead Console](#) (501-12 Instrument Panel and Console, Removal and Installation).
14. Install the interior rear view mirror.

Refer to: [Interior Rear View Mirror](#) (501-09 Rear View Mirrors, Removal and Installation).
15. Connect the headliner wiring harness and secure the clips.
16. Install the speaker grille.

17. Install the cowl side trim panel.

Refer to: [Cowl Side Trim Panel](#) (501-05 Interior Trim and Ornamentation, Removal and Installation).

18. Install the glove compartment.

Refer to: [Glove Compartment](#) (501-12 Instrument Panel and Console, Removal and Installation).

19. Install the rear quarter trim panel.

20. Install the loadspace securing ring and tighten the Torx screw.

Torque: 25 Nm

21. Install the D-pillar trim panels.

Refer to: [D-Pillar Trim Panel](#) (501-05 Interior Trim and Ornamentation, Removal and Installation).

22. Install the C-pillar trim panels.

Refer to: [C-Pillar Trim Panel](#) (501-05 Interior Trim and Ornamentation, Removal and Installation).

23. Install the B-pillar trim panels.

Refer to: [B-Pillar Upper Trim Panel](#) (501-05 Interior Trim and Ornamentation, Removal and Installation).

24. Install the A-pillar trim panels.

Refer to: [A-Pillar Trim Panel](#) (501-05 Interior Trim and Ornamentation, Removal and Installation).

Interior Trim and Ornamentation - Headliner Vehicles With: Tilting Roof Opening Panel

Removal and Installation

Removal



CAUTION: Make sure that the wiring harnesses are correctly located.

NOTE: If a headliner is to be replaced, it is imperative that the washer hose and wiring harness are installed to their original positions. Failure to follow these instructions may impede the side air curtain module performance.

NOTE: Note the position of the wiring harnesses to aid installation.

1. Remove both A-pillar trim panels.

Refer to: [A-Pillar Trim Panel](#) (501-05 Interior Trim and Ornamentation, Removal and Installation).

2. Remove both B-pillar upper trim panels.

Refer to: [B-Pillar Upper Trim Panel](#) (501-05 Interior Trim and Ornamentation, Removal and Installation).


3. Remove both C-pillar trim panels.

Refer to: [C-Pillar Trim Panel](#) (501-05 Interior Trim and Ornamentation, Removal and Installation).

4. Remove both D-pillar upper trim panels.


Refer to: [D-Pillar Trim Panel](#) (501-05 Interior Trim and Ornamentation, Removal and Installation).

5. Remove the loadspace securing ring.



E77860

6. Remove the rear quarter trim panel.



E76929


7. Remove the glove compartment.

Refer to: [Glove Compartment](#) (501-12 Instrument Panel and Console, Removal and Installation).


8. Passenger side: Remove the cowl side trim panel.

Refer to: [Cowl Side Trim Panel](#) (501-05 Interior Trim and Ornamentation, Removal and Installation).

9. Passenger side: Remove the speaker grille.




E77223



10.


E77861



11.

E77862

12.



13. Remove the interior rear view mirror.

Refer to: [Interior Rear View Mirror](#) (501-09 Rear View Mirrors, Removal and Installation).


14. Remove both sun visors.




15. Remove the overhead console.

Refer to: [Overhead Console](#) (501-12 Instrument Panel and Console, Removal and Installation).



16. Remove both front interior lamps.



17. Remove the center interior lamp.




18. Remove the rear interior lamp.



E77864

19. Remove the 4 passenger assist handles.




E49689

20. Position the front seats fully forward.


21. Position the rear seats fully forward.

22. Release the rear of the headliner.





E77621

23. Release the front door seals.



E77866

24. Disconnect the washer jet hose.




E77867


25. Release the headliner.




E79518



26. Disconnect the roof opening panel motor electrical connector.



27. **NOTE:** This step requires the aid of another technician.
Remove the headliner.



28. **NOTE:** Do not disassemble further if the component is removed for access only.
Remove the tire pressure monitoring system receiver.

29. **NOTE:** Make sure that this component is installed to the noted removal position.

Remove the washer jet hose.

30. Remove the 14 clips.




E79520

31. **NOTE:** Note the position of the wiring harnesses to aid installation.

Remove the headliner wiring harness.

Installation



E77871

1.  **CAUTION:** Make sure that the wiring harnesses are correctly located.
 - Align the yellow tape on the wiring harness to the corner of the headliner.

2. Install the clips.
3. Install the washer jet hose.
4. Install the tire pressure monitoring system receiver.
5. **NOTE:** This step requires the aid of another technician.
Install the headliner.
6. Connect the roof opening panel motor electrical connector.
7. Connect the washer jet hose.
8. Attach the front door seals.
9. Attach the rear of the headliner.
10. Reposition the rear seats.
11. Reposition the front seats.
12. Install the passenger assist handles.
13. Install the rear interior lamp.

14. Install the center interior lamp.

15. Install the front interior lamps.

16. Install the overhead console.

Refer to: [Overhead Console](#) (501-12 Instrument Panel and Console, Removal and Installation).

17. Install the sun visors.

18. Install the interior rear view mirror.

Refer to: [Interior Rear View Mirror](#) (501-09 Rear View Mirrors, Removal and Installation).

19. Connect the headliner wiring harness and secure the clips.

20. Install the speaker grille.

21. Install the cowl side trim panel.

Refer to: [Cowl Side Trim Panel](#) (501-05 Interior Trim and Ornamentation, Removal and Installation).

22. Install the glove compartment.

Refer to: [Glove Compartment](#) (501-12 Instrument Panel and Console, Removal and Installation).

23. Install the rear quarter trim panel.

24. Install the loadspace securing ring and tighten the Torx screw.

Torque: 25 Nm

25. Install the D-pillar trim panels.

Refer to: [D-Pillar Trim Panel](#) (501-05 Interior Trim and Ornamentation, Removal and Installation).

26. Install the C-pillar trim panels.

Refer to: [C-Pillar Trim Panel](#) (501-05 Interior Trim and Ornamentation, Removal and Installation).

27. Install the B-pillar trim panels.

Refer to: [B-Pillar Upper Trim Panel](#) (501-05 Interior Trim and Ornamentation, Removal and Installation).


28. Install the A-pillar trim panels.

Refer to: [A-Pillar Trim Panel](#) (501-05 Interior Trim and Ornamentation, Removal and Installation).

Interior Trim and Ornamentation - Engine Cover TD4 2.2L Diesel

Removal and Installation


Removal



1.




2.



3. Torque: 10 Nm

4. Torque: 10 Nm




Installation

1. To install, reverse the removal procedure.

Interior Trim and Ornamentation - Cowl Side Trim Panel


Removal and Installation

Removal



1.

2. NOTE: Do not disassemble further if the component is removed for access only.



E75249

Installation

1. To install, reverse the removal procedure.

Interior Trim and Ornamentation - Front Scuff Plate Trim Panel


Removal and Installation

Removal


1. Remove the B-pillar lower trim panel.

Refer to: [B-Pillar Lower Trim Panel](#) (501-05 Interior Trim and Ornamentation, Removal and Installation).


2.




3.



4.





5. NOTE: Do not disassemble further if the component is removed for access only.

Installation

1. To install, reverse the removal procedure.
2. Remove the B-pillar lower trim panel.


Refer to: [B-Pillar Lower Trim Panel](#) (501-05 Interior Trim and Ornamentation, Removal and Installation).

Interior Trim and Ornamentation - Rear Quarter Trim Panel

Removal and Installation


Removal

1.




E76943

2. Remove the loadspace scuff plate.




E76944


3. Release the liftgate seal.




E76945




4.



5.





6. Release the rear door seal.





7.

8. If installed, remove the loadspace lamp.



9. Remove the rear quarter trim panel.






E76930

10. **NOTE:** Do not disassemble further if the component is removed for access only.

Remove the 7 clips.



E76931

11. Remove the access cover.

Installation

1. Install the access cover.
2. Install the clips.
3. Install the rear quarter trim panel.
4. Install the loadspace lamp.
5. Install the loadspace roller blind.
6. Secure the rear door seal.
7. Install the loadspace securing ring and tighten the Torx screw.

Torque: 25 Nm

8. Install the loadspace stowage tray.
9. Secure the liftgate seal.
10. Install the loadspace scuff plate.
11. Install the spare wheel cover.

