

Published: 11-May-2011

Daytime Running Lamps (DRL) -

Item	Specification
Daytime running lamps	Full intensity low beam headlamps are permanently illuminated when the vehicle is being driven. For additional information, refer to: Daytime Running Lamps (DRL) (417-04 Daytime Running Lamps (DRL), Description and Operation).

Daytime Running Lamps (DRL) - Daytime Running Lamps (DRL)

Description and Operation

OVERVIEW

DRL use the full intensity low beam headlamps which are permanently illuminated when the vehicle is being driven. DRL are used in a number of markets and there are 2 systems to cover these markets.

For additional information, refer to: [Exterior Lighting](#) (417-01 Exterior Lighting, Description and Operation).

DRL CANADIAN MARKET

DRL for this market use full intensity low beam headlamps. The side marker lamps, tail lamps and license plate lamps will be on, but instrument cluster illumination will be off. DRL are active when the following parameters are met:

- PARK is not selected on automatic transmission selector lever
- Power mode 6 (ignition on) detected by the auxiliary junction box
- Handbrake is not applied.

NOTE: If the rotary switch on the light switch module is moved to the headlamp position, DRL are deactivated and normal side lamp and headlamp functionality is operational.

NOTE: Adaptive Front lighting System (AFS) (where fitted) is non-functional when the DRL are active unless the rotary switch on the light switch module is moved to the headlamp position.

NOTE: When DRL are active, the headlamp flash function using the left hand steering column multifunction switch will operate normally.

NOTE: When DRL are active, the headlamp powerwash function is non-functional, unless the rotary switch on the light switch module is moved to the headlamp position.

The high beam headlamp function using the left hand steering column stalk switch will be deactivated. When the selector lever is in the PARK position on automatic transmission vehicles, DRL are turned off. This is to reduce battery discharge during long periods of engine idling in cold climate conditions. When the selector lever is moved from the PARK position, normal DRL functionality is restored.

When the handbrake is applied, DRL are turned off to reduce battery discharge.

DRL DENMARK, HOLLAND, NORWAY, SWEDEN, FINLAND AND POLAND

NOTE: DRL for Poland is on vehicles from 2008MY.

DRL for these markets use full intensity low beam headlamps. Side lamps and license plate lamps will be on, but instrument cluster illumination will be off. DRL are active when the following parameters are met:

- Power mode 6 (ignition on) detected by the auxiliary junction box
- The rotary switch on the light switch module is in the off position.

NOTE: When DRL are active, the headlamp flash function using the left hand steering column multifunction switch will operate normally. The high beam headlamp function using the left hand steering column stalk switch will be deactivated.

NOTE: When DRL are active, the headlamp powerwash function is non-functional, unless the rotary switch on the light switch module is moved to the headlamp position.

If the rotary switch on the light switch module is moved to the side lamp or headlamp positions, DRL are deactivated and normal side lamp and headlamp functionality is operational.

Daytime Running Lamps (DRL) - Daytime Running Lamps (DRL)

Diagnosis and Testing

Principles of Operation

For a detailed description of the daytime running lamps system, refer to the relevant Description and Operation section in the workshop manual.

REFER to: [Daytime Running Lamps \(DRL\)](#) (417-04 Daytime Running Lamps (DRL), Description and Operation).

Inspection and Verification

1. Verify the customer concern.
2. Visually inspect for obvious signs of damage and system integrity.

Visual Inspection

Electrical
<ul style="list-style-type: none">● Fuses (refer to the electrical guide)● Bulbs● Switches● Electrical connectors● Wiring harness

3. If an obvious cause for an observed or reported concern is found, correct the cause (if possible) before proceeding to the next step.
4. If the cause is not visually evident, check for Diagnostic Trouble Codes (DTCs) and refer to the relevant Diagnostic section and DTC Index.