

Published: 11-May-2011

Exterior Trim and Ornamentation -


Torque Specifications

Description	Nm	lb-ft
Rear outer quarter panel moulding fixings	4	3

Exterior Trim and Ornamentation - Rear Quarter Panel Moulding

Removal and Installation

Removal



1.

Installation

1. To install, reverse the removal procedure.